

## Serger – Changing Threads


### Step 1: Clip the old thread

- At the spool stand on the back of the serger, clip the thread to be changed.
- Note, this tutorial demonstrates changing a single thread. To change all the thread, simply perform these same steps on all four threads at the same time.



### Step 2: Tie in the new one

- Remove the old spool from its stand and replace it with the new one
- Tie the end of the new thread to the end of the old one



### Step 3: Run the serger

- Without using fabric, run the serger to pull the new thread along its path.
- Pull lightly on the thread tail to help extend the threads faster.



### Step 4: If needed, hand-thread the needle

- If replacing one or both of the needle threads, the knot will frequently not go through the eye of the needle.
- In that case, lift the presser foot to release tension on the thread, cut the new thread just above the knot, lower the presser foot again, and hand-thread the needle.

